

StoneWall[®] SELECT[®]


Installation Manual Addendum

Installing 45° Inside Corners


Please Note:

You will need 4x8x16" solid split face units.

Make a 55° angle cut on the 16" unit at 8" as shown (45° plus 10° to allow for the angle built into the StoneWall SELECT unit).



The 8" dimension maintains the running bond (half bond).



1st Course

Place angle cut unit as shown. Place StoneWall SELECT unit against cut angle and your inside 45° angle is formed.

Apply adhesive to angle cut unit.


Note: A 10° pie shaped gap will be created where the square side of the angle cut unit contacts the 10° angle of the StoneWall SELECT unit.

2nd Course

Place StoneWall SELECT unit over the angle cut unit. Place a new angle cut unit as shown. Lay additional StoneWall SELECT units.

Apply adhesive to angle cut unit.

Proceed with additional courses, alternating the angle cut units, as shown.



StoneWall SELECT...
another perfectly proportioned
product from:

ICD[®] Corporation
Innovative Concrete Design

Web Site www.selecticd.com
Toll Free 800 / 394-4066